

TIME TO REPLACE YOUR WINDSHIELD WIPERS?

Are your windshield wipers squeaking and leaving behind streaks? It may be time to replace those old wipers with some new ones. Here are a few guidelines to help you replace your wipers.

WHEN BUYING NEW WINDSHIELD WIPER BLADES:

Windshield wipers vary. Be sure to check the length and style of the current wiper blades that you are replacing on your vehicle.

NOTE: The driver and passenger wiper blade length can be different.



THE TWO STYLES OF WIPER BLADES:

BEAM STYLE BLADE:




TRADITIONAL STYLE BLADE:




HOW TO REPLACE WINDSHIELD WIPER BLADES:


ATTACHMENT STYLE: HOOK BLADE




1. Raise the wiper arm away from the windshield and flip the rubber blade so it faces up.




2. Hold down the lever to release the hook from the wiper blade.



3. Lift up and remove the hook from the old wiper blade.




4. Insert the hook into the new wiper blade.




5. Pull down hook to secure it in place.


ATTACHMENT STYLE: PIN BLADE




1. Raise the wiper arm away from the windshield and flip the rubber blade so it faces up.




2. Disengage the lock by pulling the tab up.



3. Pull the pin out of the hole on the side of the old wiper blade.



4. Pull the tab up slightly, and then insert the wiper arm pin into the new wiper blade.



5. Push down firmly on the tab to lock the new wiper blade in place.

